

KUARZ – SHOPPING BASKET ASSEMBLY – INSTRUCTIONS

Installation of the Basket on the Kuarz Steering Column

Important Information

This installation requires **basic DIY skills and appropriate tools**.

It should be carried out by a person familiar with drilling and using power tools.

This tutorial explains how to install the basket **directly onto the existing steering column, without removing or disassembling the steering column**.

Ensure the scooter is **switched off and parked on a stable surface** before starting the installation.

Tools Required

- Printed drilling template
- Soft adhesive tape (masking tape recommended)
- Electric drill
- 3 mm drill bit
- 8 mm drill bit
- 13 mm drill bit
- Deburring tool or small file (to clean the hole edges)
- Appropriate screwdriver or wrench for the basket fixation screw

We recommend using **new or well-maintained drill bits** and a **high-speed drill machine** for accurate drilling.

Installation Steps

Step 1 – Prepare the drilling template

Print the drilling template provided with the installation guide. This template indicates the correct drilling positions on the steering column.

Step 2 – Position the template

Using soft adhesive tape, attach the drilling template to the steering column in the position shown in the video.

Use tape that is not too strong in order to avoid damaging the paint.

Step 3 – Drill the pilot holes

Start by drilling the two holes using a **3 mm drill bit**.

This pilot drilling helps prevent damage to the plastic cover.

Step 4 – Enlarge the holes

Enlarge the holes progressively using an **8 mm drill bit**, and then finish with a **13 mm drill bit**, which is the final required diameter.

Step 5 – Identify the internal thread

While drilling with the **13 mm drill bit**, you will feel the internal screw thread once the drill passes through the plastic cover.

This indicates the location where the basket fixation will be screwed in.

Step 6 – Clean the hole edges

Use a deburring tool or similar tool to carefully clean the edges of the drilled holes.

Step 7 – Install the basket fixation

Insert and tighten the basket fixation screw into the threaded hole to secure the basket support.